


## RFT Rafena Rubens Typ FE855C1

Schaltplan:



Kondensatoren:

## Keramik

500V= (und alle anderen nicht unterscheidbaren Spannungsfestigkeiten wie 160V=, 350V=)

| Pos   | Wert    |
|-------|---------|
| C301a | 500 pF  |
| C301b | 500 pF  |
| C301c | 500 pF  |
| C310  | 20 pF   |
| C305  | 500 pF  |
| C316  | 20 pF   |
| C34   | 2000 pF |
| C313  | 1200 pF |
| C312  | 10 pF   |
| C309  | 4000 pF |
| C28   | 4000 pF |
| C29   | 4000 pF |
| C31   | 120 pF  |
| C42   | 120 pF  |
| C63   | 4000 pF |
| C67   | 100 pF  |
| C64   | 100 pF  |
| C65   | 4000 pF |
| C66   | 4000 pF |
| C68   | 500 pF  |
| C76   | 500 pF  |
| C60   | 30 pF   |
| C61   | 30 pF   |
| C59   | 35 pF   |
| C58   | 30 pF   |
| C57   | 35 pF   |
| C89   | 100 pF  |
| C94   | 75 pF   |
| C111  | 300 pF  |
| C114  | 300 pF  |

250V~

| <b>Pos</b> | <b>Wert</b>   |
|------------|---------------|
| C26        | 2000 pF       |
| C24        | 5000 pF       |
| C62        | 5000 pF       |
| C56        | 5000 pF       |
| C46        | 0,2 $\mu$ F   |
| C47        | 0,025 $\mu$ F |
| C37        | 4000 pF       |
| C38        | pF            |
| C43        | 4000 pF       |

500V= (und alle anderen nicht unterscheidbaren Spannungsfestigkeiten wie 500V~)

| <b>Pos</b> | <b>Wert</b>  |
|------------|--------------|
| C74        | 1000 pF      |
| C77        | 1000 pF      |
| C80        | 10000 pF     |
| C90        | 2000 pF      |
| C91        | 2000 pF      |
| C119       | 0,1 $\mu$ F  |
| C125       | 0,1 $\mu$ F  |
| C106       | 1300 pF      |
| C107       | 0,05 $\mu$ F |
| C112       | 10000 pF     |
| C113       | 2000 pF      |
| C116       | 0,05 $\mu$ F |
| C302       | 2 pF         |
| <b>Pos</b> | <b>Wert</b>  |
| C314       | 60 pF        |
| C73        | 0,05 $\mu$ F |
| C50        | 5000 pF      |
| C88        | 0,1 $\mu$ F  |
| C93        | 0,2 $\mu$ F  |
| C85        | 0,05 $\mu$ F |
| C86        | 0,05 $\mu$ F |
| C87        | 0,05 $\mu$ F |
| C96        | 0,1 $\mu$ F  |
| C99        | 0,1 $\mu$ F  |
| C101       | 0,1 $\mu$ F  |
| C100       | 3000 pF      |
| C136       | 10000 pF     |
| C79        | 5000 pF      |
| C118       | 10000 pF     |

| <b>Pos</b> | <b>Wert</b>   |
|------------|---------------|
| C108       | 0,025 $\mu$ F |
| C109       | 0,5 $\mu$ F   |
| C110       | 0,05 $\mu$ F  |
| <b>Pos</b> | <b>Wert</b>   |
| C134       | 5000 pF       |
| C51        | 15 pF         |
| C78        | 5000 pF       |
| C318       | 3000 pF       |
| C319       | 3000 pF       |
| C320       | 3000 pF       |
| C323       | 3000 pF       |
| C321       | 80 pF         |
| C303b      | 5 pF          |
| C304       | 3000 pF       |
| C98        | 50 $\mu$ F    |
| C115       | 0,5 $\mu$ F   |
| <b>Pos</b> | <b>Wert</b>   |
| C45        | 100 $\mu$ F   |
| C44        | 250 $\mu$ F   |
| C81        | 250 $\mu$ F   |
| C82        | 16 $\mu$ F    |
| C22        | 50 $\mu$ F    |
| C48        | 50 $\mu$ F    |
| C49        | 10 $\mu$ F    |
| C128       | 100 $\mu$ F   |
| C132       | 50 $\mu$ F    |
| C97        | 16 $\mu$ F    |
| C130       | 100 $\mu$ F   |

From:

<http://www.loetlabor-jena.de/> - **Lötlabor Jena**

Permanent link:

[http://www.loetlabor-jena.de/doku.php?id=projekte:rft\\_rafena\\_rubens\\_restoration&rev=1389772894](http://www.loetlabor-jena.de/doku.php?id=projekte:rft_rafena_rubens_restoration&rev=1389772894)

Last update: **2014/01/15 08:01**

